



TOP TERMINATION AND END LAP
PREPRUFE WATERPROOFING SYSTEM

DRAWING: PRE-048

SCALE: Not to scale

EFFECTIVE DATE: 01-03-2019



Top Termination and End Lap

Prior to Membrane Installation, Review the Preprufe[®] Data Sheet

Surface Prep

All surfaces must be sound and solid to eliminate movement during the concrete pour. Substrate must be regular and smooth with no gaps or voids greater than 15 mm. The surface should also be free from loose aggregate and sharp protrusions as outlined in the Preprufe[®] Data Sheet section on Surface Preparation.

Detailing

1. Apply Preprufe field membrane according to standard installation procedures.
2. Apply termination bar to Preprufe membrane.
3. Centre Preprufe CJ Tape to cover termination bar and roll firmly.
4. Protect top of termination of membrane from exposure.
5. For end lap, overlap successive membrane rolls by 75 mm.
6. Apply Preprufe Tape, centred over the lap. (Refer to PRE 031 and PRE 032)

Special Notes

Preprufe membranes should not be used in areas where they will be permanently exposed to sunlight, weather or traffic. Protect membrane from sunlight as quickly as possible after installation.